



Nastavenie D-Link DIR-600 na režim Access Point (Prístupový bod)




Zapojenie zariadení

Poznámka: zariadenie je možné použiť aj ako switch (prepínač).

1. Zariadenie je nutné nastaviť do výrobných nastavení stlačením tlačidla RESET (pomocou ceruzky, pera, ...). Pripojte ethernetový (sieťový) kábel do jedného z LAN portov na DIR-600 a druhý koniec kábla do PC/notebooku. Kábel s pripojením na zariadenie Huawei HG8245 zapojte do WAN portu (nie do LAN portov!).



2. V internetovom prehliadači zadajte IP adresu zariadenia (uvedená na zariadení, príp. v manuáli) a prihláste sa pomocou administrátorských údajov (uvedené na zariadení, príp. v manuáli) kliknutím na tlačidlo Log In.



3. Nastavenie bezdrôtového pripojenia (WiFi): v ľavej časti ponuky kliknite na možnosť Wireless Setup a potom na možnosť Manual Wireless Connection Setup.



4. Pre vašu novú bezdrôtovú sieť nastavte rovnaký názov a heslo, ako má vaša pôvodná bezdrôtová sieť na HG8245 (možnosť Wireless Network Name a pre heslo možnosť Network Key). Ďalej nastavte typ zabezpečenia a šifrovania vašej siete podľa obrázka na WPA/WPA2 a AES. Nastavenia uložíte kliknutím na možnosť Save Settings.

DIR-600	SETUP	ADVANCED	TOOLS	STATUS	SUPPORT
INTERNET	WIRELESS NETWORK				Helpful Hints... - Changing your Wireless Network Name is the first step in securing your wireless network. We recommend that you change it to a familiar name that does not contain any personal information. - Enable Auto Channel Selection let the router can select the best possible channel for your wireless network to operate on. - Enabling WMM can help control latency and jitter when transmitting multimedia content over a wireless connection. - Enabling Hidden Mode is another way to secure your network. With this option enabled, no wireless clients will be able to see your wireless network when they perform a scan to see what's available. In order for your wireless devices to connect to your router, you will need to manually enter the Wireless Network Name on each device. - If you have enabled Wireless Security, make sure you write down the WEP Key or Passphrase that you have configured. You will need to enter this information on any wireless device that you connect to your wireless network.
WIRELESS SETTINGS	Use this section to configure the wireless settings for your D-Link router. Please note that changes made in this section may also need to be duplicated on your wireless client. To protect your privacy you can configure wireless security features. This device supports three wireless security modes including: WEP, WPA and WPA2. Save Settings Don't Save Settings				
NETWORK SETTINGS	WIRELESS NETWORK SETTINGS Enable Wireless : ☒ Always ☐ New Schedule Wireless Network Name : HUAWEI-s1D310 (Also called the SSID) 1. Enable Auto Channel Selection : ☒ Wireless Channel : 10 Transmission Rate : Best (automatic) (Mbit/s) Wireless Mode : 802.11 Mixed(n/g/b) Band Width : 20/40 Mhz(Auto) Enable Hidden Wireless : ☐ (Also called the SSID Broadcast)				
IPv6	WIRELESS SECURITY MODE Security Mode : Enable WPA/WPA2 Wireless Security (mixed mode) 2.				
	WPA/WPA2 WPA/WPA2 requires stations to use high grade encryption and authentication. Cipher Type : AES 3. PSK / EAP : PSK Network Key : wT4@n2Qo 4. (8~63 ASCII or 64 HEX) 5. Save Settings Don't Save Settings				

5. V ľavej časti kliknite na možnosť INTERNET a tam kliknite na Manual Internet Connection Setup.

Product Page : DIR-600 Hardware Version : Bx Firmware Version : 2.12OR

D-Link

DIR-600	SETUP	ADVANCED	TOOLS	STATUS	SUPPORT
INTERNET WIRELESS SETTINGS NETWORK SETTINGS IPv6	INTERNET CONNECTION If you are configuring the device for the first time, we recommend that you click on the Internet Connection Setup Wizard, and follow the instructions on the screen. If you wish to modify or configure the device settings manually, click the Manual Internet Connection Setup. INTERNET CONNECTION SETUP WIZARD If you would like to utilize our easy to use Web-based Wizard to assist you in connecting your new D-Link Systems Router to the Internet, click on the button below. Internet Connection Setup Wizard Note: Before launching the wizard, please make sure you have followed all steps outlined in the Quick Installation Guide included in the package. MANUAL INTERNET CONNECTION OPTION If you would like to configure the Internet settings of your new D-Link Router manually, then click on the button below. 2. Manual Internet Connection Setup	Helpful Hints... • If you are new to networking and have never configured a router before, click on Internet Connection Setup Wizard and the router will guide you through a few simple steps to get your network up and running. • If you consider yourself an advanced user and have configured a router before, click Manual Internet Connection Setup to input all the settings manually.			

6. Zaškrtnite možnosť Enabled Access Point Mode a nastavenie uložte (tlačidlo Save Settings).

Product Page : DIR-600 Hardware Version : Bx Firmware Version : 2.12OR

D-Link

DIR-600	SETUP	ADVANCED	TOOLS	STATUS	SUPPORT
---------	-------	----------	-------	--------	---------

INTERNET
WIRELESS SETTINGS
NETWORK SETTINGS
IPv6

WAN

Use this section to configure your Internet Connection type. There are several connection types to choose from: Static IP, DHCP, PPPoE, PPTP, and L2TP. If you are unsure of your connection method, please contact your Internet Service Provider.

Note : If using the PPPoE option, you will need to remove or disable any PPPoE client software on your computers.

ACCESS POINT MODE

Use this to disable NAT on the router and turn it into an Access Point.

☒ Enabled Access Point Mode **1.**

INTERNET CONNECTION TYPE

Choose the mode to be used by the router to connect to the Internet.

My Internet Connection is :

DYNAMIC IP (DHCP) INTERNET CONNECTION TYPE :

Use this Internet connection type if your Internet Service Provider (ISP) didn't provide you with IP Address information and/or a username and password.

Host Name :

Primary DNS Server :

Secondary DNS Server : (optional)

MTU :

MAC Address :

2.

Helpful Hints...

- Internet Connection:** When configuring the router to access the Internet, be sure to choose the correct Internet Connection Type from the drop down menu. If you are unsure of which option to choose, please contact your Internet Service Provider (ISP).
- Support:** If you are having trouble accessing the Internet through the router, double check any settings you have entered on this page and verify them with your ISP if needed.

7. Ukladanie nastavení a reštartovanie zariadenia bude trvať približne 70 sekúnd.

DEVICE MODE

The device is changing to AP mode.

The device will dynamically get an IP address from DHCP server.

Please check the DHCP server for the IP address of the device.


Or use UPnP tools to discover the device.

Waiting time : 65

8. Ethernetový kábel, ktorý prepája váš PC so zariadením D-Link DIR 600, odpojte a následne zapojte, aby zariadenie Huawei HG8245H pridelilo vášmu PC novú IP adresu a pokračujte nastavením zariadenia Huawei HG8245H.

Nastavenie zariadenia Huawei HG8245H






Zapojenie zariadení


1. V internetovom prehliadači zadajte IP adresu zariadenia (uvedená na zariadení, príp. v manuáli) a prihláste sa pomocou administrátorských údajov (uvedené na zariadení, príp. v manuáli) kliknutím na tlačidlo Login.



- Po prihlásení v hornej časti kliknite na možnosť **Status** a potom na možnosť **User Device Information**, ktorú nájdete v ľavej časti ponuky. Tu sa zobrazia všetky zariadenia pripojené k zariadeniu HG8245. Nájdite riadok s názvom **dlinkrouter** alebo riadok s typom vášho D-Link zariadenia (napr. DIR-300, DIR-600, ...). Na konci tohto riadka kliknite na možnosť **Network Application** (na obrázku zvýraznená v modrom rámečku). Ak sa zariadenie s názvom dlinkrouter alebo zariadenie typu D-Link nenachádzajú v tabuľke, tak počkajte pár minút, kým sa zariadenia spárujú.



- Tu kliknite na možnosť **Configure Reserved DHCP IP Addresses**.



- V kolónke zmeňte pôvodnú hodnotu na **192.168.100.130** tak, ako je na obrázku, a nastavenia uložte kliknutím na tlačidlo **Apply**. Zariadenie reštartujte odpojením a následným pripojením k elektrickej sieti.

